

## Bronze Level VR7 Toolbars and Menus

The screenshot displays the AutoSPRINK VR7 Bronze software interface. The main window shows a project tree on the left with 'OH System' selected. The central area is filled with various toolbars and fly-out menus. The 'File' menu includes options like 'New Drawing', 'Save', and 'Exit'. The 'Auto Draw' menu contains 'Column Grid', 'Connect', and 'Hangers...'. The 'Commands' menu lists 'Assign Heights to Columns', 'Break Pipes/Walls/Lines against Target', and 'Merge Pipelines'. The 'Wizards' menu includes 'Grid System' and 'Tree System'. The 'Tools' menu is divided into 'Tools' (e.g., 'Selection Cursor', 'FDC', 'Fittings') and 'Tools (continued)' (e.g., 'Arc', 'Circle', 'Crosshatch'). The 'Printing' menu includes 'Preview', 'Print...', and 'Hydraulic Reports...'. The status bar at the bottom indicates '1 selected Elev: 19'-11" S: 0 Length: 8'-0" (7'-10 1/2") @ 1 1/2" (1.6390) # Off Foot'.

The all new VR7 'Simple Interface' with Fly-Out Toolbars, shown above, is available in all Levels of the program. The program features, commands, wizards, toolbars and toolbar button arrangements vary with the program Level. Only the Bronze Level tools are shown here.

